STARR HID USA
HEADLIGHT COMPONENT LIST

1. Headlight Housing
2. Headlight Lens
3. Headlight Projector Shroud
4. Headlight Projector Lens
5. Headlight Projector
6. Projector Actuator Module
7. Blue Projector Actuator Wires
8. Projector Actuator Input Harness
9. H4 Headlight Control Harness
10. H4 Headlight Control Module
11. H4 Headlight Wire Diode
12. H4 to H13 Adapter Wire Harness
13. Relay Harness
14. Relay
15. Black Relay Socket
16. White Relay Projector Actuator Connector
17. Relay Fuse
18. Relay Positive Wire
19. Relay Negative Wire
20. Relay Ballast Power Connector
21. HID Ballast
22. Ballast input Power
23. Ballast Output to Bulb Wire
24. D1S HID Bulb
25. Projector Bulb Retaining Cap
26. Projector Bulb Retaining Bracket
27. Projector Bulb Retaining Screws
28. Headlight Housing Mounting Points
29. Moisture Vent / Breather Port
30. Ballast to Bulb Output Cable
31. Ballast Side of Cable
32. Bulb Side of Cable
33. H4 Side of Adapter Wire Harness
34. H13 Side of Adapter Wire Harness

WWW.STARRHIDUSA.COM

WWW.STARRHIDUSA.COM



WWW.STARRHIDUSA.COM

STARR



WWW.STARRHIDUSA.COM



WWW.STARRHIDUSA.COM



WWW.STARRHIDUSA.COM

STARR



WWW.STARRHIDUSA.COM



WWW.STARRHIDUSA.COM


7
26
25
29
10
8
28
6
F4572SA11018
WWW.STARRHIDUSA.COM
STARR



WWW.STARRHIDUSA.COM

STARR